

90° Angle Spindle RA-200

OPERATION MANUAL

OM-K0049E 003

Thank you for purchasing 90° Angle Spindle " RA - 200 ". This Spindle is designed for drilling on side faces, or working on corners difficult to work or unfit for working with straight type Spindles. The E2530 Control Unit, Brushless Motor or Air Motor and Air Line Kit with Lubricator combination are required to drive this Spindle. Read this and all the associated component Operation Manuals carefully before use. Always keep this Operation Manual in a place where a user can referred to for reference at any time.

1. CAUTIONS FOR HANDLING AND OPERATION

- Read these warnings and cautions carefully and only use in the manner intended.
- These warnings and cautions are intended to avoid potential hazards that could result in personal injury to the operator or damage to the device. These are classified as follows in accordance with the seriousness of the risk.

| Class | Degree of Risk |
|----------------|--|
| WARNING | A safety hazard could result in bodily injury or damage to the device if the safety instructions are not properly followed. |
| CAUTION | A hazard that could result in light or moderate bodily injury or damage to the device if the safety instructions are not followed. |

WARNING

- This Spindle is not a hand tool. It is designed to be used on CNC machines or special purpose machines.
- Do not touch the cutting tool while it is running. It is very dangerous.
- Wear safety glasses, dust mask and use a protective cover around the Spindle whenever the Spindle is rotating.
- Never connect, disconnect or touch the Power Cord Plug or Motor Cord Plug with wet hands. This may cause an electric shock.
- Never operate or handle the Spindle and brushless motor until you have thoroughly read the Operation Manuals and safe operation has been confirmed.
 - To prevent injuries / damages, check the Spindle, brushless motor and cutting tool for proper installation, before operating the Spindle and brushless motor.
 - Before disconnecting the Spindle and brushless motor, always turn the control power off and turn the compressed air supply to the CONTROLLER off. Then it is safe to remove the Spindle and brushless motor.
- When installing a Spindle to a fixed base, make sure the fixed base is grounded in order to avoid the risk of an electric shock.
- When installing a tool, tighten the collet correctly and check again the collet before use. Do not over-tighten the collet. This may cause damage to the Spindle.
- Do not use bent, broken, chipped, out of round or sub-standard tools, as this may cause them to shatter or explode. Tools with fractures or a bent shank will cause injury to the operator. When using a new tool, rotate it in a low speed and increase speed gradually for safety.
- Do not exceed the maximum recommended allowable tool speed. For your safety, use speeds below the maximum allowable speed.
- Do not apply excessive force. This may cause tool slippage, tool damage, injury to the operator or loss of concentricity and precision.

CAUTION

- Do not exceed the maximum allowable motor speed of 20,000min⁻¹ (rpm).
- The speed reducer is always used to connect between the air motor AM - 300 • AM - 310 and RA - 200.
- Do not drop or hit this Spindle, as shock can damage to the internal components.
- Be sure to clean the collet, the inside of the Spindle before replacing the tool. If ground particles or metal chips stick to the inside of spindle or the collet, damage to the collet or Spindle can occur due to the loss of precision.
- When cleaning a Spindle, stop the motor and remove debris with a soft brush or a cloth. Do not blow air into the Spindle with compressed air as foreign particles or cutting debris may get into the ball bearing.
- Always clean the tool shank before installing the tool in the Spindle.
- When sizing the correct collet size to the tool shank diameter, a tolerance of +0 ~ - 0.01mm is strongly recommended.
A tool shank within the +0 ~ - 0.1mm range is mountable, however, this may cause poor concentricity and or insufficient tool shank gripping force.
- Select suitable products or tools for all applications. Do not exceed the capabilities of the Spindle or tools.
- Do not stop the supply cooling air for motor during operation of the machine. Removing the air pressure from the Spindle causes a loss of purging, allowing the Spindle to ingest coolant. This will cause damage to the Spindle.
- Carefully direct coolant spray to the tool. Do not spray directly on the Spindle body. If large amount spray directly on the Spindle, it may cause excess load of the motor rotation with loss of durability to the Spindle.
- Stop working immediately when abnormal rotation or unusual vibration are observed. Immediately, please check the content of section " 13. TROUBLESHOOTING ".
- Always check if the tool, collet are damaged before and after operating.
- If the collet show signs of wear or damage, replace it before a malfunction or additional damage occurs.
- After installation, repair, initial operation, or long periods of non operation, please refer to section " 11. BREAK-IN PROCEDURE " detailed in Table. 2. When checking the Spindle, no vibration or unusual sound should be observed during rotation.
- Do not disassemble, modify or attempt to repair this Spindle. Additional damage will occur to the internal components. Service must be performed by NSK NAKANISHI or an authorized service center.
- When using this Spindle for mass production, please consider the purchase of an additional Spindle to be used as a back-up in case of emergency.

2. BASIC PACKAGE

When opening the package, check if it includes all items listed in " Table.1 Packing List Contents ". In the event of any shortage, please contact either NAKANISHI (see the " 4. CONTACT US " section) or your local dealer.

Table. 1 Packing List Contents

| | | |
|------------------|---|---------------------------|
| Spindle • • 1pc. | Collet ϕ 3.0mm (CHS - 3.0) or ϕ 3.175mm (CHS - 3.175) • • 1pc.* (For U.S. market ϕ 3.175mm (CHS - 3.175)) | Wrench (7 x 5.1) • • 1pc. |
|------------------|---|---------------------------|

| | | |
|---|--------------------------|---------------------------|
| Wrench (8 x 5), (20 x 24) • • 1pc. Each. | Inspection Card • • 1pc. | Operation Manual • • 1set |
|---|--------------------------|---------------------------|

* The collet is attached to the Spindle.

3. WARRANTY

We provide a limited warranty for our products. We will repair or replace the products if the cause of failure is due to the following manufactures defects. Please contact us or your local distributor for details.

- Defect in manufacturing.
- Any shortage of components in the package.
- Where damaged components are found when initially opening the package.
(This shall not apply if the damage was caused by the negligence of a customer.)

4. CONTACT US

For your safety and convenience when purchasing our products, we welcome your questions. If you have any questions about operation, maintenance and repair of the product, please contact us.

Contact Us

- For U.S. Market

| | |
|--------------------|--|
| Company Name | : NSK America Corp. |
| Business Hours | : 8:00 to 17:00 (CST) (closed Saturday, Sunday and Public Holidays) |
| U.S. Toll Free No. | : +1 800 585 4675 |
| Telephone No. | : +1 847 843 7664 |
| Fax No. | : +1 847 843 7622 |
| Website | : www.nskamericacorp.com |
- For Other Markets

| | |
|----------------|--|
| Company Name | : NAKANISHI INC. |
| Business Hours | : 8:00 to 17:00 (JST) (closed Saturday, Sunday and Public Holidays) |
| Telephone No. | : +81 289 64 3520 |
| e-mail | : webmaster-ie@nsk-nakanishi.co.jp |

5. FEATURES

- The Spindle is designed for drilling on side faces, or working on corners difficult to work or unfit for working with straight type Spindles.
- The Spindle housing is made from precision ground, hardened, stainless steel (SUS) with an outside diameter of ϕ 22.8 mm.
- Various sizes of collets are available CHS 0.8mm - 3.0mm. Standard collet is CHS 3.0mm or CHS 3.175mm.
(For U.S. market CHS 3.175mm.)

6. SPECIFICATIONS AND DIMENSIONS

6 - 1 Specifications

| | | |
|------------------------------------|---------------------|--|
| Model | RA - 200 | |
| Maximum Motor Rotation Speed | For Air Motor | 30,000min ⁻¹ (rpm) In case of using the reducer. |
| | For Brushless Motor | 20,000min ⁻¹ (rpm) |
| Maximum rotating speed at the tool | For Air Motor | 5,100min ⁻¹ (rpm) In case of using the reducer. |
| | For Brushless Motor | 13,330min ⁻¹ (rpm) |
| Appropriate Motor | For Air Motor | AM - 300R / L, AM - 300RA / LA, AM - 310R / L, AM - 310RA / LA |
| | For Brushless Moto | EM25 - 5000 - 4M / 5M / 8M, EM25 - 5000 - J4 / J5 / J8 |
| Reduction Ratio | 1 / 1.5 | |
| Weight | 165g | |
| Noise Level at 1m distance | Less than 70dB (A) | |

| | Temperature | Humidity | Atmospheric Pressure |
|--|-------------|------------------------------|----------------------|
| Operation Environment | 0 - 40°C | MAX.75% (No condensation) | 800 - 1,060hPa |
| Transportation and Storage Environment | -10 - 50°C | 10 - 85% | 500 - 1,060hPa |

CAUTION

Use less than the maximum allowable motor speed 20,000min⁻¹ (rpm).
DO NOT exceed the maximum allowable motor speed 20,000min⁻¹ (rpm) for the spindle.
Always use the reducer between the air motor (AM - 300 • AM - 310) and RA - 200.

< Option >

| | |
|---|---|
| Collet (CHS - <input type="checkbox"/>) | ϕ 0.8mm ~ ϕ 3.0mm in 0.1mm increments and ϕ 2.35mm, ϕ 3.175mm |
|---|---|

6 - 2 Outside View




Fig. 1

7. CONNECTION OF THE SPINDLE TO THE MOTOR

CAUTION

Make sure your hands and all interlocking parts of the Spindle and motor are clean before connecting the motor to the Spindle. This is critical in preventing contaminants from entering the motor or Spindle.

Align the thread on the front end of the brushless motor / reducer and the rear of the Spindle, and turn the Spindle clockwise. If the drive shaft of the brushless motor / reducer does not engage properly to the drive dog on the spindle, it may only turn approximately two threads before stopping. DO NOT FORCE THEM TOGETHER. Loosen the Spindle from the brushless motor / reducer, rotate the Spindle shaft by hand then re-try. The drive shaft and the drive dog must be fully engaged. When fully engaged, secure the brushless motor / reducer and Spindle using the provided 20mm wrench (Fig. 2) .




Fig. 2

8. CHANGING THE TOOL

CAUTION

Do not tighten the collet without inserting a tool or dummy bur as this will result in damage to the collet.

RECOMMENDATION

Please set the cutting tools to minimize the overhang amount. 13mm is the maximum amount of overhang to maintain high accuracy and safety.

- Set the provided 7mm wrench on the Spindle.
- Place the provided 5mm wrench on the chuck and turn it counterclockwise to loosen the collet and remove the tool.
- Clean the collet, then insert the new tool and tighten the collet by turning clockwise. Do not over-tighten.




Fig. 3

9. REPLACING THE COLLET

- Remove the tool according to the section "8. CHANGING THE TOOL" procedure above. (Fig. 4).
- Place the provided 7mm wrench on the spindle shaft, and turn the top of the collet counterclockwise to remove the collet.
- Install the new collet into the Spindle by turning it clockwise.




Fig. 4

10. INSTALLATION OF THE SPINDLE

WARNING

When installing a Spindle to a fixed base, make sure the fixed base is grounded in order to avoid the risk of an electric shock.

CAUTION

- When installing a Spindle, do not hit, drop or cause shock to the Spindle. This may cause damage to internal components and result in malfunctions.
- When mounting the Spindle, be sure to secure within Clamping Area etched on the motor spindle O.D. If the Spindle is installed incorrectly, damage to the internal components is possible.
- Cautions when tightening the securing bolts on to a Split Type Holder
Do not over-tighten the bolt. This will cause damage to Spindle's precision.
Tighten the bolt until the Spindle body can not be rotated by hand within the fixture.
Extreme tightening is not necessary or recommended.
Apply working force and check that the Spindle is tight before using.

- When mounting a Spindle, refer to the Clamping Area etched on the Spindle (Fig. 5).




Fig. 5

- When installing a Spindle to the holder, recommended installation method is shown Fig 6. Refer to "3 How to fabricate the Split Type Holder". If this is not possible, install as shown in Fig. 7.




Fig. 6

Fig. 7

Fig. 8

CAUTION

Do not allow set screws to come directly in contact with the Spindle body as shown in Fig. 8, as this will result in damage to the Spindle housing and internal components. When installing, never clamp directly over the bearings, as this will result in bearing damage (Refer to Fig. 9).




Fig. 9

- How to fabricate the Split Type Holder
 - Rough bore the inside diameter of the Split Type Holder.
 - Cut a slit. (Ex. Slit 2mm) wide.
 - Tighten the Screw for Removal and Force Open the Slit Area.
 - Insert a spacer (Ex. thickness = 2mm) into the Slit Area.
 - Loosen the Screw for Removal, and tighten the fastening bolt with its specified torque.
 - Finish the Split Type Holder so that the inside diameter of the Split Type Holder is $\phi 22.8$ with its tolerance range from -0.01mm to -0.015mm , and its roundness and cylindricity of less than $5\mu\text{m}$.
 - When inserting the Spindle loosen the Fastening Bolt, and tighten the Screw for Removal, widening the Slit Area.




Fig. 10

CAUTION

- How to confirm the correct tightening or clamping of the Spindles in the holder : In case of use a brushless motor.
Measure the current value of the Control Unit's power cord by the clamp meter.
Fasten the holder so that the increase in the no-load current value (during rotation at the maximum rotation speed) with the Spindle fastened is 10mA (for type 200V / 230V) or less, compared to the no-load current value (during rotation at the maximum rotation speed) without fastening the Spindle. Do not over-tighten the Fastening Bolt. It may damage Spindle's precision and shorten the life of the bearings.
- The final responsibility for ensuring holder's safety for use in a given application is left to the designer of the equipment in which NAKANISHI's Spindle is installed.
NAKANISHI offers Spindles with a wide variety of capabilities and specifications.
Please carefully check the Spindle's specifications against the requirements of your equipment and verify suitability and safety of the Holder prior to initial use.

11. BREAK-IN PROCEDURE

During transportation, storage or installation, the grease inside the bearings will settle. If the Spindle is suddenly run at high-speed, the grease will be ejected from the bearings, causing excessive heat that will cause bearing damage. After installation, repair, initial operation, or long periods of non operation, please follow the break-in procedure detailed in Table. 2.

Table. 2

| Steps | | 1 | 2 | 3 | 4 |
|---|---------------------|---------------------|--|--|--------|
| Air Pressure (MPa) | For Air Motor | 0.1 | 0.2 | 0.3 | 0.4 |
| Rotation Speed (min ⁻¹) (rpm) | For Brushless Motor | 5,000 | 10,000 | 15,000 | 20,000 |
| Rotation Time (min) | | 15 | 10 | 10 | 15 |
| Items to Check | | No Abnormal Noises. | The Spindle housing temperature during the break-in process should not exceed 20 degrees C (36 degrees F) above ambient temperature. Should the Spindle exceed this limit, rest the Spindle for at least 20 minutes and re-start the break in procedure from the beginning. If the housing temperature rises again and exceeds 20 degrees C (36 degrees F) above ambient temperature, check the Spindle and motor for proper installation. | The Spindle housing temperature during the break-in process should not exceed 20 degrees C (36 degrees F) above ambient temperature. | |

12. CAUTIONS IN USING GRINDSTONES AND TOOLS

CAUTION

The maximum surface speed or rpm is always specified for a grindstone. Do not exceed the maximum speed with reference to the calculating chart below. Always follow the grindstone manufacturer's recommendations.

$$\text{Surface Speed (m/s)} = \frac{3.14 \times \text{Diameter (mm)} \times \text{rotation speed (min}^{-1}\text{) (rpm)}}{1,000 \times 60}$$

- The proper surface speed for general grindstones is 10 - 30 m/s.
- Do not exceed 13mm of overhang for mounted grindstones as shown in Fig. 11. If the overhang must exceed 13mm, reduce the motor speed in accordance with Table. 3.
- Dress the grindstone prior to use.
- Do not use cutting tools with bent or broken shanks, cracks or excessive run-out.
- For grinding, the maximum depth of cut should not exceed 0.01mm radially or axially. Reciprocate the tool several times after each pass to eliminate tool pressure.
- Always operate cutting tools within the allowable recommended speed of the cutting tools. Use of a cutting tool outside of the allowable speed of the cutting tools could cause damage to the spindle and injury to the operator.
- Keep the cutting tool shank and collet clean. If contaminants are left in the collet, excessive run-out will cause damage to the cutting tool and or spindle.
- Do not strike or disassemble the Spindle.
- Please set the cutting tools to minimize the overhang amount. 13mm is the maximum amount of overhang to maintain high accuracy and safety.

Table. 3 Overhang and Speed

| Overhang (mm) | Max. Speed (min ⁻¹) (rpm) |
|---------------|---------------------------------------|
| 20 | N x 0.5 |
| 25 | N x 0.3 |
| 50 | N x 0.1 |

* N = Max. Operating Speed with 13mm overhang.




Fig. 11

13. TROUBLESHOOTING

If a problem or concern occurs, please check the following prior to consulting your dealer.

| Trouble | Cause | Inspection / Corrective Action |
|--|--|---|
| Spindle does not rotate or rotate smoothly. | The Spindle ball bearings have been damaged. | Replace the ball bearings. (Return to NAKANISHI dealer service.) |
| | The motor has been damaged. | Replace the motor. (Return to NAKANISHI dealer service.) |
| Overheating during rotation. | Cutting debris has contaminated the ball bearing, and the ball bearings are damaged. | Replace the ball bearings. (Return to NAKANISHI dealer service.) |
| Abnormal vibration or noise during rotation. | The tool shank is bent. | Replace the tool. |
| | Cutting debris has contaminated the ball bearings. The spindle ball bearings have been damaged. | Replace the ball bearings. (Return to NAKANISHI dealer service.) |
| Tool slippage. | Collet chuck is not correctly installed. | Check and clean the collet. Reinstall the collet. |
| | The collet is worn. | Replace the collet. |
| High run-out. | The tool is bent. | Change the tool. |
| | Collet chuck is not correctly installed. | Secure the collet correctly. |
| | The collet is worn. | Replace the collet. |
| | Inside of the Spindle is worn. | Replace the Spindle shaft. (Return to NAKANISHI dealer service.) |
| | Contaminants inside the collet or the Spindle. The Spindle ball bearings have been damaged. | Clean the collet and the inside of the taper and Spindle. Replace the ball bearings. (Return to NAKANISHI dealer service.) |

In case of using a brushless motor, refer to brushless motor and E2530 Control Unit Operation Manuals. In case of using an air motor, refer to the air motor and the Air Line Kit Operation Manuals.

14. DISPOSAL OF THE SPINDLE

When disposal of a Spindle is necessary, follow the instructions from your local government agency for proper disposal of industrial components.